

# Eichrom PET Shipping System for Two Unit Dose Shields Specification Sheet

Part Number: SH-PET-SYS-UDS

## SPECIFICATIONS

QTY	COMPONENT	WEIGHT
1	<b>SH-PET-CASE-UDS</b> <ul style="list-style-type: none"> <li>• Polyethylene shell with polyethylene foam cushioning</li> <li>• Heavy duty zinc-plated steel hinge, handles, and latches</li> <li>• Two place contoured lead casting with brushed stainless steel sleeves and cover plates                             <ul style="list-style-type: none"> <li>* No exposed lead</li> </ul> </li> <li>• Zinc plated steel Label Frames                             <ul style="list-style-type: none"> <li>* No clear plastic envelope required</li> </ul> </li> <li>• Overall Size: 10 in. X 8.5 in. X 12.25 in. tall</li> </ul>	53 LB
2	<b>SH-PET-UDS</b> <ul style="list-style-type: none"> <li>• Two-piece assembly</li> <li>• Triple start threads for ¼ turn operation</li> <li>• All surfaces brushed stainless steel                             <ul style="list-style-type: none"> <li>* No exposed lead</li> </ul> </li> <li>• O-ring seal</li> <li>• Overall Size: 2.15 in. diameter X 10.60 in. tall</li> </ul>	11 LB
2	<b>SH-PET-LBL</b> <ul style="list-style-type: none"> <li>• Yellow II laminated shipping label</li> <li>• Two sided, Yellow II and Empty</li> </ul>	N/A
<b>SH-PET-SYS-UDS</b>		<b>TOTAL WEIGHT: 75 LB</b>



## REGULATIONS



Meets DOT Yellow II Type A packaging requirements when shipping up to 955 mCi (35.3 GBq) and 610 mCi (22.6 GBq) of 18F (FDG)



Meets IATA Dangerous Goods Regulations, 64th Edition Sections 5.0.4.3, 10.5, 10.6.0 and 10.6.1 thru 10.6.3.5